

Spare Parts For APCs**WMZ551NB NORINCO APC (6X6)**

S.No.	Parts	Specification Code Number	Remark
1	Tyre (14.00R20)	WZ551.11.01	
2	Air Brake Hose (Front, Middle, Rear)	WMZ551NB	
3	Air compressor Belt	117.9088	
4	Air Filter	WZ 551.04.15	
5	Brake shoe with Friction shims	350104	
6	Clutch Assy	WZ551A.07	
7	Clutch Booster Cylinder	JQF-43	
8	Fuel coarse filter	1171768	
9	Fuel Filter	1171770/11711111	
10	Distributing Box Middle Driving Shaft	WZ551.73.02	
11	Distributing switch Assy	WZ 551.05.15	
12	Engine belt	241.7875	
13	Engine Oil Filter	G030 8514KZ	
14	Exhaust brake valve	JQF-16	
15	Flow continuity valve	JQF - 15	
16	Fuse JB (50 A), (30 A, 20 A 10 A)	JB (50 A), (30 A, 20 A 10 A)	
17	Fuse 250 A	BSH (250 A)	
18	Fuse 100 A	KB (100 A)	
19	Gear Oil Pump	WMZ551NB	
20	Hand Brake Control Valve	WMZ551NB	
21	Instrument board Assy	WMZ 551A.39	
22	Kilometer Cable	WMZ551NB	
24	Main Cylinder	JQF-10	
25	Pressure Plate	WMZ551NB	
26	Return piping protected valve	14314706	
27	Side Light Assy	WMZ551NB	
28	Spring Break Chamber	JQF-20DA (Y.Z)	
29	Starter Moter Assy	216 4298KZ	
30	Universal Coupling Assy	2202010F1	
31	Wheel tire valve Assy	WZ550.11.30	
32	Wiper motor and blade	Wz551.2647	

नोट:

१. उक्त भेहिकलको क्याटलक बुकमा नभेटिएको भेहिकल पार्टसहरूको स्पेशिफिकेशन नं.को बदला भेहिकल मोडल नं. राखिएको ।

२. NA102, NA103 र NA105 APC मा खराब भएको पार्टसलाई मध्येनजर गरी स्पेयर पार्टस उल्लेख गरिएको ।

APC (ZFB 05) Wheeled Aurmored Vehicle (RHD) Shanxi Baoji

S.No.	Parts	Specification Code Number	Remark
1	A/c Compressor Belt	ZFBO05	
2	Air Filter Element	ZFBO05	
3	Alternator Belt	ZFBO05	
4	Battery	ZFBO05	
5	Brake Caliper Assy	ZFBO05	
6	Brake Friction plate	ZFBO05	
7	Brake master chamber	ZFBO05	
8	Brake master cylinder	ZFBO05	
9	Clutch Cover Throw out Bearing, hub Flange (Three Separate set)	ZFBO05	

[Handwritten signatures and initials]

10	Clutch hose	ZFBO05	
11	Clutch Main Chamber	ZFBO05	
12	Clutch master cylinder	ZFBO05	
13	Clutch Plate	FD350DC-1601200Y1	
14	Clutch Slave cylinder	ZFBO05	
15	Door lock ASSY (Rear))	ZFBO05	
16	Door lock ASSY Left	ZFBO05	
17	Door lock ASSY Right	ZFBO05	
18	Fuel Filter Assy	ZFBO05	
19	Hydraulic steering pump	ZFBO05	
20	Ignition switch	ZFBO05	
21	Oil filter Assy	ZFBO05	
22	Oil pressure Sensor	ZFBO05	
23	Parking Brake Disc Assy	ZFBO05	
24	Pressure plate	FD350DC-1601100-16C1034	
25	Rear View Mirror Assembly (L) Side Mirror	ZFBO05	
26	Rear View Mirror Assembly (R) Side Mirror	ZFBO05	
27	Release Bearing	ZFBO05	
28	RPM meter Sensor	ZFBO05	
29	Starter assy	ZFBO05	
30	Transmission shaft crossing axle	ZFBO05	
31	Wiper Motor	ZFBO05	

नोट: उक्त भेहिकलको पार्टस क्याटलकमा बुक नभएकोले स्पेशिफिकेशन नं. को बदला भेहिकल मोडल नं. राखिएको छ ।

NORINCO VN4 (4x4) APC

S.No.	Parts	Specification Code Number	Remark
1	2 Way Valve	3526E1-010	
2	3 ways Pipe adaptor	WZ551A.10.404	
3	4 Way Pipe line Exhaust Valve Assy	QLY4606.10.54	
4	4 Way return Piping Protected Valve	QLY4606.10.08	
5	Air Dryer Assy	YZ0011A.10.08	
6	Air Dryer - 4 Way Pipe line Assy	QLY4606.10.12	
7	ARS Device	360010.IV	
8	ARS Valve right Tri-Valve Assy	QLY4606.10.34	
9	Assistant tie rod Assy	32104000170	
10	Bellow Brake Valve Assy	YZ0011.06.01	
11	Booster Pump Assy	QLY4606.10.02	
12	Box with 36 Tooth Angle 36	TYZX-JX.03	
13	Brake Capiler Assy (Left)	YF3501TMA-100	
14	Brake Shoe Assy	YZ0011.95.07	
15	Clutch Release Bearing	VN4 (4x4)	
16	Clutch Booster cylinder	YZ0011.21.04	
17	Clutch main cylinder Assy	YZ0011.21.05	
18	Clutch Servo cylinder	JQF-43	
19	Column Assy	QLY4606.20.01	
20	Diaphragm Brake chamber Assy	JQF-18	
21	Exhaust Assy of foot brake	QLY4606.10.66	
22	Exhaust Brake Valve Assy	YZ0011A.10.10	
23	Foot Brake- Foot Relay Assy I	QLY4606.10.23	
24	Foot Relay Left ABS Assy	QLY4606.10.28	
25	Fuel filter (Fleet Guard)	FF5052	
26	Fuel filter (Fleet Guard)	Fs 1280	
27	Fuel Sensor	CUT-52A	
28	Gas Pressure Sensor 404	CTY-02-1.0-G3	

[Handwritten signatures and initials]

29	Handle Assy	WZ551D.29.0128	
30	Intergrated Electromagnetic Oil Valve	JDB2414A/F1280	
31	Intermediate Driving Shaft	3405TM-010	
32	Left ABS Tri- Way valve Assy	QLY4606.10.29	
33	Magnetic Fuel Cutting Valve and Connection Plug	VN4 (4x4)	
34	Oil connecting Pump	QLY4606.05.16	
35	Oil Filter (Fleet Guard)	LF3349	
36	Oil Inlet Tube of Pump	QILY4606.05.17	
37	Oil Suction Filter	WU-16X100-J	
38	Parking Brake Valve	CP3517CA010	
39	Power Steering gear	3401G-010	
40	Pressure plate Assy	1601Z6-090	
41	Reducing Valve Assy	QLY4606.10.05	
42	Spring Brake chamber	3519CF4-010F	
43	Spring Damper Assy	YZ0011.12.05	
44	Starter motor Assy (24V)	5271460-21YB054-19L00151	
45	Stop Working Cylinder	1174698	
46	Swing Arm	QLY4606.20.001	
47	Tie Rod Assy	3210400018	
48	Type Clutch Plate (395 mm Dia)	1601Z56-130-CI9083	
49	Tyre Assy	YZ0011.11.01	
50	Wiper Assy	DC1056B	

नोट:

१. उक्त भेहिकलको क्याटलक बुकमा नभेटिएको भेहिकल पार्टसहरुको स्पेशिफिकेशन नं.को बदला भेहिकल मोडल नं. राखिएको ।

२. NA 306, NA 330, VN4 (4X4) APC मा खराब भएको पार्टसलाई मध्येनजर गरी स्पेयर पार्टस उल्लेख गरिएको ।

